



A Watch You Can Trust

**INSTRUCTION MANUAL FOR
WATCH CALIBRE
VD75**



WARNING



THIS PRODUCT CONTAINS A BUTTON BATTERY

If swallowed or placed inside any part of the body, the battery can cause severe or fatal injuries within 2 hours or less.

Button batteries are hazardous whether new or used. Keep batteries out of reach of children.

If you think the battery may have been swallowed or placed inside any part of the body, seek immediate medical attention. Contact the Australian

Poisons Information Centre immediately on 13 11 26

(New Zealand 0800 764 766) for 24 / 7 fast, expert advice.

Instruction Manual

LORUS

CAL. VD75, VD76, VD86, VX7J, VX7N, VX7P, VX7R, VX9J, VX9N, VX9P, VX9R


LORUS

CHARACTERISTICS


	Hour	Minute	Second	Date	Day	24h
VD75	●	●	● (Small)	●	●	
VD76	●	●	● (Small)	●	●	
VD86	●	●	● (Small)	●	●	
VX7J	●	●	●	●	●	●
VX7N	●	●	●	●	●	●
VX7P	●	●	●	●	●	
VX7R	●	●	●	●	●	●
VX9J	●	●	●	●	●	●
VX9N	●	●	●	●	●	●
VX9P	●	●	●	●	●	
VX9R	●	●	●	●		●

DISPLAY AND CROWN / BUTTONS


VD75, VD76




VD86




VX7J




VX7N




VX7P




VX7R




VX9J




VX9N



VX9P




VX9R



VD75, VD76, VD86, VX7 series

■ HOW TO SET THE TIME AND DAY

(Day hand is not available for VX7R.)



- 1 Pull out the crown to the second click when the second hand is pointing at the 12 o'clock position.
- 2 Turn the crown clockwise to advance the hour and minute hands until the day hand is set to the desired day of the week.
- 3 Turn the crown to set the time.
- 4 Push the crown back into the normal position in accordance with a time signal.

NOTES

- To advance the day hand quickly, turn back the hour and minute hands 4 to 5 hours beyond the point the day changes (between 11:00 p.m. and 4:00 a.m.), and then advance them again until the day hand is set to the next day.
*The day hand will not move back by turning the crown counterclockwise.
- When adjusting the day hand, turn the crown slowly.
- When setting the minute hand, advance it 4 to 5 minutes ahead of the desired time and then turn it back to the exact time.
- The 24-hour hand moves correspondingly with the hour hand (VX7J, VX7N, VX7R).
- When setting the hour hand, check that the 24-hour hand is correctly set (VX7J, VX7N, VX7R).

■ HOW TO SET THE DATE




- 1 Pull out the crown to the first click.
- 2 Turn the crown counterclockwise to set the date hand to the desired date.
- 3 Push the crown in.

NOTES

- Do not set the date hand between 10:00 p.m. and 1:00 a.m. (VD75, VD76, VD86), or, 9:00 p.m. and 4:00 a.m. (VX7 series). Otherwise, the date may not change properly. If it is necessary to set the date during this time period, first change the time to any time outside it, and set the date and then reset the time.
- While setting the date hand, check that it moves properly in one-day increments.
- It is necessary to adjust the date on the first day after a 30-day month and February.

VX9 series

■ HOW TO SET THE TIME




- 1 Pull the crown out to the first click position when the second hand is at the 12 o'clock position.
- 2 Turn to set the time taking AM/PM into consideration.
- 3 Push the crown back to the normal position.

NOTES

- The 24-hour hand moves correspondingly with the hour hand (except VX9P).
- When setting the hour hand, check that the 24-hour hand is correctly set (except VX9P).
- When setting the minute hand, advance it 4 to 5 minutes ahead of the desired time and then turn it back to the exact time.

■ HOW TO SET DATE AND DAY OF THE WEEK



A Day Correction (except VX9R): With each pressing of the button A, the day hand advances to the next day.

B Date Correction: With each pressing of the button B, the date hand advances one day.

NOTES

- Do not set the date and the day hands between 9:00 p.m. and 4:00 a.m. Otherwise, they may not move properly.
- While setting the date and the day hands, check that they move properly in one-day increments.
- It is necessary to adjust the date on the first day after a 30-day month and February.

■ LUMIBRITE WATCH

- If your watch is a LORUS LUMIBRITE watch, it has following features.

LORUS LUMIBRITE watches absorb and store light energy from natural and artificial light sources and emit light in the dark. They are made of environmentally friendly material, and therefore, are harmless to human beings and the environment.

- With a full charge, LORUS LUMIBRITE watches glow in the dark hours longer than conventional luminous watches of this type. If exposed to a light of more than 500 lux (i.e., the brightness of a typical office) for approximately 10 minutes, or direct sunlight for 2 minutes, they will glow for hours.
- Since LORUS LUMIBRITE watches emit the light they store, the brightness will decrease gradually over time. The length of time they will glow may also differ slightly depending on such factors as the brightness of and distance from the light source used to charge the watch.

■ BATTERY CHANGE

The miniature battery SEIKO SR626SW (VD75, VD76, VD86) or SR927SW (VX series), which powers your watch should last approximately 3 years. However, because it is inserted at the factory, the actual life of the battery once in your possession may be less than 3 years.

Be sure to replace the battery to prevent any possible malfunction as soon as it runs down. To replace the battery we recommend taking the watch to a local watch repair shop.

■ CARE OF YOUR LORUS WATCH

• BATTERY



CAUTION

Do not expose the old battery to fire or recharge it. Keep it at a place beyond the reach of children. If a child swallows it, consult a doctor immediately.

• WATER RESISTANT

Condition of use Indication on the dial/ case back	Accidental contact with water, such as splashes and rain	Swimming and taking a shower	Skin diving	Scuba diving
NO INDICATION	NO	NO	NO	NO
WATER RESISTANT	YES	NO	NO	NO
WATER RESISTANT (50M/50 BAR)	YES	YES	NO	NO
WATER RESISTANT (100M/10 BAR OR ABOVE)	YES	YES	YES	NO

* If your watch is 200 M/20 BAR, 100 M/10 BAR or 50 M/5 BAR water resistant, it is so indicated on the dial/case back.

- Do not operate the buttons when the watch is wet.
- If the watch is exposed to salt water, rinse it in fresh water and then wipe it thoroughly dry.

Caution:

Leather straps are not water resistant except so indicated, even if the watch head is water resistant.

• ALLERGIC REACTION

Because the case and band touch the skin directly, it is important to clean them regularly. If not, shirt sleeves may be stained and those with delicate skin may develop a rash. Please wear the watch with some play to avoid any possible allergic reaction. If you develop a rash on your wrist, stop wearing and consult a physician.

• MAGNETISM

Your watch will be adversely affected by strong magnetism. Keep it away from close contact with magnetic objects.

• SHOCKS AND VIBRATIONS

Your watch may be worn for normal sports activities, but be careful not to drop it or hit it on hard surfaces.

• TEMPERATURE

Your watch is preadjusted so that constant accuracy may be insured at normal temperature.

■ SERVICE

When your LORUS watch requires repair or servicing, please see the enclosed WARRANTY/GUARANTEE.

Printed in China